


## How to clean Cabin Air Filter

1. Remove all 4 screws



2. Remove glove box
3. Locate and remove filter



4. Clean Air filter

Before



5. Put everything back together.

After

